

a:		A:	A
b:	ᵇ	B:	B
c:		C:	C
d:	ᵈ	D:	D
e:		E:	E
f:	ᶠ	F:	F
g:		G:	G
h:	ᵃ	H:	H
i:		I:	I
j:	ᵃ	P:	P
k:	ᵃ	Q:	Q
l:	ᵃ	R:	R
m:	ᵃ	S:	S
n:	ᵃ	T:	T
p:	ᵃ	W:	W
q:	ᵃ	X:	X
r:	ᵃ	Y:	Y
<:	ᵃ	Z:	Z
>:	ᵃ	Y:	Y
x:	ᵃ	z:	z
		.	.

Small numbers as themselves:

1234567890

Larger numbers (5x7) as 'capital numbers:

i.e. '!' through ')', respectively

!@#\$%~&* ()

top

left

bottom

right

These characters
define connection
points in component
definitions

Pieces of 16 pin
packages

8/09/78

'unconnected' pin

This figure shows the available characters in "Gates32.al"
These characters are normally read in by SIL as FONT 3

(this picture is available as <SIL>GATES

XEROX	Project	Reference	File	Designer	Rev	Date	Page
PARC	S I L	Gates Symbols	Gates32.sil	R Bates	A	7/12/79	31