

PIA #1 ASSIGNMENTS

1A0	1	2	DRUM DRIVE MOTOR	0-ON 1-OFF
1A1	1	2	EL STRIPS	0-ON 1-OFF
1A2	3	4	DEVELOPER PADDLEWHEEL MOTOR	0-ON 1-OFF
1A3	3	4	ERASE LAMP	1-ON 0-OFF
1A4	5	6	CLEANER BRUSH MOTOR	0-ON 1-OFF
1A5	5	6	CLEANER ROLL MOTOR	0-ON 1-OFF
1A6	9	8	CLEANER BRUSH BIAS	0-ON 1-OFF
1A7	9	8	CLEANER ROLL BIAS	0-ON 1-OFF
1B0	11	10	VACCUUM BLOWER	1-ON 0-OFF
1B1	11	10	FUSER POWER CONTROLLER AND DRIVE	1-ON 0-OFF
1B2	13	12	LASER POWER SUPPLY	1-ON 0-OFF
1B3	13	12	ROS POWER SUPPLY	1-ON 0-OFF
1B4	1	2	BMI MODULE	1-ON 0-OFF
1B5	1	2	AC POWER ENABLE	1-ON 0-OFF
1B6	3	4	FUSER TRANSPORT CLOCK (ON-OFF)	1-ON 0-OFF
1B7	3	4	FUSER TRANSPORT DIRECTION	1-FORWARD 0-REVERSE

PIA #2 ASSIGNMENTS

2A0	5	6	#1 HOUSING MOTOR	0-ON 1-OFF
2A1	5	6	#2 HOUSING MOTOR	0-ON 1-OFF
2A2	9	8	#3 HOUSING MOTOR	0-ON 1-OFF
2A3	9	8	#4 HOUSING MOTOR	0-ON 1-OFF
2A4	11	10	#1 HOUSING CLEAN-OFF	0-REVERSE 1-FORWARD
2A5	11	10	#2 HOUSING CLEAN-OFF	0-REVERSE 1-FORWARD
2A6	13	12	#3 HOUSING CLEAN-OFF	0-REVERSE 1-FORWARD
2A7	13	12	#4 HOUSING CLEAN-OFF	0-REVERSE 1-FORWARD
2B0	1	2	CHARGE CORONA	0-ON 1-OFF
2B1	11	10	TRANSFER CORONA	0-ON 1-OFF
2B2	3	4	PRE-CLEAN CORONA	0-ON 1-OFF
2B3	13	12	DETACK/PRE-TRANSFER CORONA	0-ON 1-OFF
2B4	5	6	#1 HOUSING BIAS	0-ON 1-OFF
2B5	1	2	#2 HOUSING BIAS	0-ON 1-OFF
2B6	9	8	#3 HOUSING BIAS	0-ON 1-OFF
2B7	3	4	#4 HOUSING BIAS	0-ON 1-OFF

PIA #3 ASSIGNMENTS

