

a:		A:	A
b:	Ḃ	B:	B
c:		C:	C
d:	Ḍ	D:	D
e:		E:	E
f:	Ḟ	F:	F
g:		G:	G
h:	Ḩ	H:	H
i:		I:	I
j:	Ḵ	J:	J
k:	Ḷ	K:	K
l:	Ḹ	L:	L
m:		M:	M
n:	Ṃ	N:	N
p:	Ṇ	P:	P
q:	Ṙ	Q:	Q
r:	Ṛ	R:	R
<:	Ṗ	S:	S
>:	Ṛ	T:	T
x:	Ṙ	U:	U
		V:	V
		W:	W
		X:	X
		Y:	Y
		Z:	Z
		[unconnected]:	.

Small numbers as themselves:

1 2 3 4 5 6 7 8 9 0

Larger numbers (5x7) as 'capital numbers:

i.e. '!' through ')', respectively

! @ # \$ % ~ & * ()

top

left

bottom

right

These characters
define connection
points in component
definitions

Pieces of 16 pin
packages

8/09/78

'unconnected' pin

This figure shows the available characters in "Gates32.al"
These characters are normally read in by SIL as FONT 3

(this picture is available as <SIL>GATES

XEROX	Project	Reference	File	Designer	Rev	Date	Page
PARC	S I L	Gates Symbols	Gates32.sil	R Bates	A	7/12/79	31